

Guard, Pulley
8633

Bracket
8592

Heat Exch.
8687

3/4" Sil. Hose
80242GL

Bracket
9834

Clamp, Mtg.
8819

Tube
8920

U-Bolt
89541K

Bracket, Mounting
8593 (Not Shown)

Clamp
92268

Hose, Flexible
77225GL

Assy, Heat Exchanger
8919 1 of 2 &
Assy, Pulley Guard 9625

Reduction Bushing
LTL-SRB3412

Fitting
R-269HB-12-8


Clamp, Hose
92212

3/4" Sil. Hose
80242GL

Drain Valve
80511

Tube
8970

Assy, Coolant Heater
& Assy, Heat Exchanger
8930 2 of 2 & 8919 2 of 2



Fitting
R-30882-6-6

Fitting
R-48F-6-4

Heat Exch.
8687

Elbow Street 45 deg
LTL-SE3445

Fitting, Brass
8288

Clamp, Hose
92212

Clamp, Mounting
8819

Assy, Heat Exchanger
with Vent Line
8919 & 9658

3/4" Sil. Hose
80242GL


Clamp
92236

Elbow
21418

5/16" Hose
27003

1/4" Vent
Hose

Clamp
CL-6



Reduction Bushing
LTL-SRB3412

Fitting
R-269HB-12-8

Tube
8951


Clamp, Hose
92212 (4)

Bracket, Mounting
9542

3/4" Sil. Hose
80242GL

HTR CLNT 2250W 176D
3315033 120 VAC
3305070 240 VAC

Assy, Coolant Heater
8930



Guard, Pulley
8633

Bracket
8592

Heat Exch.
8687

3/4" Sil. Hose
80242GL

Bracket
9834

Clamp, Mtg.
8819

Tube
8920


U-Bolt
89541K

Bracket, Mounting
8593 (Not Shown)

Clamp
92268

Hose, Flexible
77225GL

Assy, Heat Exchanger
8919 1 of 2 &
Assy, Pulley Guard 9625



Elbow
LTL-E190

Union
BG150UG


Street Elbow
LTL-SE190

Nipple 14\"/>
BNG14

Nipple 2-1/2\"/>
BNGL

Flex Tube
MM-1-12

Assy, Misc Piping
Cooling Loop
9637 2 of 3



Street Elbow
LTL-SE190

RELOCATE GAUGE
HERE FOR CFP83-F10,
20, 30 FIREPUMP
COOLING LOOPS

Nipple 2-1/2"
BNGL

Union
BG150UG

Control panel with Cummins logo, gauges, and switches. Labels include: AUTO, CRANK BATT A, MANUAL, RESET/STOP, CRANK BATT B.

Assy, Cooling Loop
9659 12 volt

U-Bolt
3043T37

U-Bolt
3043T37

Bracket
8905

Assy, Misc Piping
Cooling Loop
9637 3 of 3

Heat Shield
9578

Rubber Hum
89835K

Clamp
AC400

Service Indicator
D-RAX00-2352


Tube
9576

Bracket
9561

Clamp (Not Shown)
P115204

FIELD SETTING
ENGINE SPEED SETTING
(@ PIP SETTING)
OVERSPEED SWITCH SETTING

WARNING





Hose, Fuel Line
201-6

Hose, Fuel Line
201-8

Elbow
23920-6-6

Elbow
23920-8-8

Bulkhead
6-WGTX-WLNS

Bulkhead
8-WGTX-WLNS

Fuel Line Hose Kit
9575