8830 (7001323)
Water Temp Gauge
8835 (7001361)
Decal
8829 (7001356)
Tachometer
8828 (7001324)
Oil Press Gauge
8827 (7001326)
Voltage Gauge
8831 (7001364)
Circuit Breaker
8849 (7001370)
Illumination Plug
8853 (7001368)
Illumination Plug
8879 (7000835)
Hole Plug
8847 (7001365)
Rocker Switch
8851 (7001367)
Rocker Switch
8855 (7001369)
Rocker Switch
WATER TEMP
RPM x 100
HOURS
DATCON
OIL PRESS
bar
VOLTS
Cummins
AUTO
MANUAL
RESET/
CRANK


8834 (7001317)
Bezel - Middle
8833 (5110056A)
Bezel - End
N/A (5110412)
Connector
8825 (7001363)
Enclosure


11204 (5110633)
Diode
11208 (5105274)
Diode Socket
N/A (6003)
5 Amp Fuse
N/A (7001428)
Fuse Block
8836 (7001327)
Overspeed Mod.
N/A (6007)
20 Amp Fuse
8857 (4191)
Relay
9529 (7001333)
Diode Module
8837 (7001426)
Terminal Strip
9528 (4179106)
Relay Holder
TEST
RESET
OVERSPEED
TWO ELEMENT
SPEED SWITCH
SSW675
CAUTION
ENGINE SPEED CONTROL COMPONENT
WHEN INSTALLING OR SERVICING, REFER TO PRODUCT PUBLICATION.
CRANK
TACH CAL
BATTERY
PICK-UP
TACH OUT
CRANK
OVERSPEED
1 2 3 4 5 6 7 8 9 10 11 12 13 14


8843 (N/A)
Water Temp Gauge
8829 (7001356)
Tachometer
8835 (7001361)
Decal
8841 (N/A)
Oil Press Gauge
8840 (7001455)
Voltage Gauge
8831 (7001364)
Circuit Breaker
8850 (N/A)
Illumination Plug
8854 (N/A)
Illumination Plug
8879 (7000835)
Hole Plug
8848 (N/A)
Rocker Switch
8852 (N/A)
Rocker Switch
8856 (N/A)
Rocker Switch
WATER TEMP
RPM x 100
HOURS
DATCON
OIL PRESS
psi
bar
VOLTS
Cummins
AUTO
BATT A
MANUAL
RESET/
CRANK


8834 (7001317)
Bezel - Middle
8833 (5110056A)
Bezel - End
N/A (5110412)
Connector
8825 (7001363)
Enclosure


N/A (7001428)
Fuse Block
N/A (6003)
5 Amp Fuse
N/A (6007)
20 Amp Fuse
11208 (5105274)
Diode Socket
11204 (5110633)
Diode
8836 (7001327)
Over-speed Mod.
8857 (4191)
Relay
9528 (4179106)
Relay Holder
9529 (7001333)
Diode Module
8837 (7001426)
Terminal Strip
TEST
OVERSPEED
TWO ELEMENT
SPEED SWITCH
SSW675
CAUTION
CRANK
TACH
CAL
BATTERY
PICK-UP
TACH
OUT
CRANK
OVERSPEED
1 2 3 4 5 6 7 8 9 10 11 12 13 14
7
12 13 14 15 16